



1, read EIS data and save it also calculate the key password

2, enter option ' ELS TOOL', read the esl data to make sure the ELV or ELV emulator is good



3, load the EIS data what contain the key password , use option ' load vvd-mb eis data '



4, click the 'automatic clear TP and personalized then press 'write', job finish after that

